

TEENY LED LAMP

SKU# 000125

Rated Input 5V DC, 1A

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this product. Please keep the instructions for future reference.

Warranty

- This product is covered by a 3-year warranty valid for in-store replacement or refund only.
- The warranty period starts from the date of purchase. Please retain the proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the product.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation Requirements

- Select a suitable location for this product:
 - This product is not waterproof.
 - This product is suitable for indoor use only.
 - Ensure it is on a flat and stable surface.
 - Keep away from wet, dusty, humid, direct sunlight or hot areas.
- Lay out all the components on a smooth surface and make sure no components are missing.
If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the product has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.

Battery and Charging

NOTE: This product includes a re-chargeable lithium-ion battery.



The battery is not replaceable. Do not attempt to replace the battery.

When the battery reaches its end of life, the whole product shall be replaced.

Contact your local council to safely dispose of equipment with a built-in lithium-ion battery.


- To charge the product, plug the provided cable into the USB-C charging port on the bottom of the product and connect the cable to a power adaptor (not included).

NOTE: Please ensure an appropriate power adaptor (not included) is used for charging according to the rated input (5V DC, 1A) of the product.



Operation Directions

- 1. Remove all packaging material from the product.
- 2. Select a suitable location for the product. See the installation requirements above.
- 3. Short press the switch at the bottom of the product to turn it ON/OFF.
- 4. Long press the switch at the bottom of the product to adjust the brightness.
- 5. Tap the silicon body to change through the lighting modes:
White / Red / Green / Blue / RGB cycling.



Safety Tips and Warnings

- This product is NOT suitable for children aged 3 and under.
- This product is NOT a toy. Keep out of reach of small children.
- Young children should be supervised to ensure that they do not play with this product.
- This product is for decorative purpose only.
- The light source of this product is not replaceable; when the light source reaches its end of life, the whole product shall be replaced.
- The built-in lithium-ion battery is not replaceable; when the battery reaches its end of life, the whole product shall be replaced. Contact your local council to safely dispose of equipment with a built-in lithium-ion battery.
- Always ensure the power is OFF and the product has cooled down before performing any maintenance, cleaning or adjustment to the product.
- To clean, wipe with a soft damp cloth or duster. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the product does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications	
SKU #	000125
Rated Input	5VDC 1A
Battery	Non-replaceable rechargeable lithium-ion battery
Dimensions	H:125mm W:75mm L:135mm