

TUDOR SMALL WALL BRACKET

SKU# 231465

Rated Voltage 220-240V~ 50Hz

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this luminaire. Please keep instructions for future reference.

Warranty

- This luminaire is covered by a 5-year warranty. The warranty is from date of purchase, not the date of installation.
- If the luminaire is not assembled and installed by a licensed electrician, the warranty will be void.
- Please retain proof of purchase and evidence of installation by a licensed electrician for any warranty enquiries.
- Warranty will be void if there is any damage due to improper usage or modification to the luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation Requirements

- This luminaire must be assembled and installed by a licensed electrician.
- All wiring and installation of the luminaire must adhere to the latest local and national wiring rules. e.g. AS/NZS 3000 Electrical installations.
- Do not exceed the maximum wattage rating.
- This luminaire is a Class I product and must be earthed during wiring and installation.
- This luminaire is rated IP65. This must be maintained during wiring and installation.
- Replace any cracked protective lamp shade to maintain IP65 rating when using this luminaire.
- Select a suitable location for installation:
 - This luminaire is rated against water penetration to IP65 standards, which is against low-pressure jets of water from all practicable directions.
 - This must be maintained during wiring and installation. The mounting point must support 2 times the weight of the luminaire.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.

Installation Directions

1. Ensure power to the circuit you are working on has been switched OFF before commencing any electrical work.
2. Remove all packaging material from the luminaire and be careful not to throw away accessories that may be hidden within the packaging material.
3. Remove the shade of the luminaire by loosening the fixing screws. Fig.1.
4. Remove the mounting bracket from the luminaire by loosening the side screws. Fig.1.
5. Disconnect the terminal connectors to separate the luminaire body from the terminal box. Fig.1.
6. Remove the lamp holder cover from the lamp holder before installing globe (not included). Fig.1.
7. Install a globe (not included) into the lamp holder. Do not exceed the maximum wattage rating. Fig.2.
8. Reinstall the lamp holder cover back after installing the globe. Fig.2.
9. Use the mounting bracket as a template to mark the screw positions on the wall. Fig. 3
10. Install the mounting bracket onto the wall by using appropriately sized mounting screws and anchors. Ensure the screws and anchors used are suitable for the mounting surface and the surrounding environment. Fig.3
11. Loosen the terminal grommet of AC input. Connect the mains supply wire to AC input on the terminal box. Ensure the wires are secure and no bare wires are exposed. Fig.3.

Mains Supply Wire

Earth – Yellow/Green
Neutral – Blue
Live – Brown

Luminaire Wire / Terminal Box

Yellow/Green or 
Blue or N
Brown or L


NOTE: This luminaire is a Class I product and must be earthed during the wiring and installation.

NOTE: If the loop input of the terminal connectors is unused, ensure it is closed with a stopper to maintain IP65 ratings.

12. Re-tighten the terminal grommet of AC input back onto the connector and attach terminal box back to mounting bracket. Fig.4 and Fig.5.
13. Mount the luminaire onto the mounting bracket and reconnect the plug connectors between the luminaire and the mounting bracket. Fig. 6.
14. Secure the luminaire onto the mounting bracket by tightening the side screws. Ensure the fitting is firmly attached and properly aligned. Fig. 7.
15. Refit the shade back onto luminaire by tightening the fixing screws. Fig.9.
16. After full assembly and installation, switch on the luminaire to test and enjoy your new lighting product.

RELAMPING:

1. Switch OFF the power supply to the luminaire at the mains and allow sufficient time for the lamp to cool.
2. Remove the shade by loosening the fixing screws and remove lamp holder cover from the lamp holder.
3. Remove the existing globe from the lamp holder and replace it with a new globe (not included) of the correct type and rating. Do not exceed the maximum wattage specified.
4. Refit the lamp holder covers back onto lamp holder and reinstall the shade onto luminaire and secure it by tightening the fixing screws.



Safety Tips

- Always ensure the power is OFF and the luminaire has cooled down before performing any maintenance, cleaning, changing the globe or making any adjustment to the luminaire.
- To avoid injury or damage to the luminaire, ensure that power leads and screws are secure before connecting the power.
- The luminaire must not be used if the protective shield has been cracked. Replace any cracked protective shield before using the luminaire.
- To clean, wipe with a damp clean cloth. Do NOT soak or immerse the luminaire in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications

SKU #	231465
Size	Small
Insulation Class	Class I
Rated Voltage	220-240V~ 50Hz
Rated Wattage	10W Max. (LED globe only.)
Lamp Holder	ES/E27
Weight	2.2kg
IP Rating	IP65
Dimensions	H:345mm W:190mm E:130mm