

PORTLAND FLOOR LAMP

SKU# 261521

Rated Voltage 220-240V~ 50Hz

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this luminaire. Please keep the instructions for future reference.

Warranty

- This portable luminaire is covered by a 12-month warranty valid for in-store replacement or refund only.
- The warranty period starts from the date of purchase. Please retain the proof of purchase.
- The warranty will be void, if there is any damage due to improper usage or modification to the portable luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation Requirements

- Select a suitable location for this portable luminaire:
 - Ensure it is on a flat and stable surface.
 - This portable luminaire is suitable for indoor use only.
 - Do not place flammable material near or over the portable luminaire.
 - Ensure the portable luminaire is not installed in direct line of an air vent/system.
 - If the portable luminaire is placed in an area prone to moisture, ensure that the area is well ventilated, and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- Do not exceed the maximum wattage rating.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any luminaire which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the luminaire is fully assembled and is ready to use for the first time.

Installation Directions

Remove all packaging material from the product and be careful not to throw away accessories that may be hidden within the packaging material. Place the portable luminaire on a smooth non-scratch surface to help with assembly.

1. Remove the front part of the shade from the luminaire head.
2. Install a LED GU10 lamp into the lamp holder. Do not exceed the maximum wattage rating.
3. Install the front part of the shade back onto the luminaire head.
4. Pull the cord out from the bottom joint, to remove the excess slack in the cord.
5. Place the joint onto base and align the screw holes together.
6. Secure the joint onto the base by install the 2 screws using the included allen key.
7. Install the top rod onto the top of the luminaire by turning it clockwise.

NOTE: Take care not to cross-thread or twist and damage the cord during assembly.

Pull the cord out from the bottom as you assemble.

Check the cord after every three turns when installing the top rod onto the top of the luminaire.

Relieve any twist in the cord by turning it anti-clockwise.

8. Install the bottom rod onto the top rod.

NOTE: Take care not to cross-thread or twist and damage the cord during assembly.

Pull the cord out from the bottom as you assemble.

Check the cord after every three turns when installing the bottom rod onto the top rod.

Relieve any twist in the cord by turning it anti-clockwise


9. Insert the bottom rod into the joint.

NOTE: Ensure the luminaire head is centred over the base. Do not position the head to the sides of the base.

10. Pull the cord out from the bottom joint, to remove the excess slack in the cord.
11. Secure the luminaire to the base by tightening the grub screw with the included allen key.
12. Insert the plug into the mains power socket outlet and ensure it is fully plugged in.

Turn power on at the mains power socket outlet.

13. Use the cord line foot switch to turn the portable luminaire ON/OFF.



Safety Tips

- Always ensure the power is OFF and the portable luminaire has cooled down before performing any maintenance, cleaning, changing the globe or making any adjustment to the portable luminaire.
- The external flexible cable or cord of the luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
- To avoid injury or damage to the luminaire, ensure that power leads and screws are secure before connecting the power.
- Young children should be supervised to ensure that they do not play with the portable luminaire.
- Handle the luminaire and shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications

SKU #	261521
Art. No.	206864N
Rated Voltage	220-240V~ 50Hz
Rated Wattage	10W Max.
Lamp Holder	GU10
Weight	3.0kg
Dimensions	H:1585mm W:270mm Dia:490mm