

LOCH 1LT FLOOR LAMP

SKU# 261530, 261531

Rated Voltage 220-240V~ 50Hz

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this product. Please keep the instructions for future reference.

Warranty

- This portable luminaire is covered by a 12-month warranty valid for in-store replacement or refund only.
- The warranty period starts from the date of purchase. Please retain the proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void warranty.

Installation Requirements

- Select a suitable location for this luminaire:
 - Ensure it is on a flat and stable surface.
 - This luminaire is suitable for indoor use only.
 - Do not place flammable material near or over the luminaire.
 - If the luminaire is placed in an area prone to moisture, ensure that the area is well ventilated and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- Do not exceed the maximum wattage rating.
- Compatible with GX53 lamps of 200mm or smaller.
 - SKU#121354,121359 GX53 lamps are recommended.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the luminaire is fully assembled with the globe installed and is ready to use for the first time.

Installation Directions


1. Remove all packaging material from the product and be careful not to throw away accessories that may be hidden within the packaging material. Place the luminaire on a smooth non-scratch surface to help with assembly.
2. Install the top rod (G) to the lamp holder assembly (F) followed by the middle rod (H) and bottom rod (I)
3. Install the base (L) onto the bottom rod (I)

NOTE: Take care not to cross-thread or twist and damage the cord during assembly. Pull the cord out from the bottom rod (I) as you assemble. Check the cord after every three turns when installing the top rod (G), middle rod (H) and bottom rod (I) onto the base (L). Relieve any twist in the cord by turning it anti-clockwise.
4. Install Glass shade (D) onto Lamp holder assembly (F)
5. Place metal fixing bracket (C) on top glass shade and fix into place using locking nuts (B)
6. Install a lamp (A - not included) into the lamp holder (E) of luminaire. Do not exceed the maximum rated wattage (18w).

NOTE: Compatible with GX53 lamps of 200mm or smaller.

SKU#121354,121359 GX53 lamps are recommended.

7. Select a suitable location for the portable luminaire. See the installation requirements above
8. Insert the plug (J) into the mains power socket outlet and ensure it is fully plugged in.
9. Turn power on at the mains power socket outlet.
10. Use the cord line foot switch (K) to turn the luminaire on/off.



Safety Tips

- Always ensure the power is OFF and the luminaire has cooled down before performing any maintenance, cleaning, changing the globe or making any adjustment to the luminaire.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Young children should be supervised to ensure that they do not play with the portable lamp.
- Handle the luminaire and/or shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications

SKU #	261530	261531
Colour	Chrome/Opal Glass	Aged Brass Finish/Milk Glass
Rated Voltage	220-240V~ 50Hz	
Rated Wattage	Max. 18W	
Lamp Holder	GX53	
Compatible Globes	GX53 Lamps 200mm or less	
Weight	6.2kg	
Dimensions	D:280mm H:1800	