

GARRET 1 LIGHT FLOOR LAMP

SKU# 281107, 281108.

Rated Voltage 220-240V~ 50Hz


To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this portable luminaire. Please keep instructions for future reference.

Warranty

- This portable luminaire is covered by 12 months warranty valid for in-store replacement or refund only.
- The warranty period starts from the date of purchase. Please retain the proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the portable luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation Requirements

- Select a suitable location for the portable luminaire:
 - Ensure it is on a flat and stable surface.
 - This portable luminaire is suitable for use in indoor environments only.
 - Do not place flammable material near or over the portable luminaire.
 - Ensure the portable luminaire is not installed in direct line of an air vent/system.
 - If installing the luminaire in an area prone to moisture, ensure that the area is well ventilated, and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by environmental exposure (including salt air, high humidity, moisture or condensation) is not a product fault, and as such is not covered under warranty.
- Do not exceed the maximum wattage rating.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure no components are missing, or have been damaged during transport, before assembling. Do not operate/install any luminaire which appears damaged in any way. If parts are missing or damaged, return the complete luminaire to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable luminaire is fully assembled with the lamp installed and is ready to use for the first time.



Installation Directions

1. Remove all packaging material from the portable luminaire (E & F) and lamp shade (B). Place the luminaire on a smooth non-scratch surface to help with assembly.
2. Install the top section (E) of the luminaire onto the bottom section (F) of the luminaire together by turning it clockwise.

NOTE: Avoid cross-threading the rods and do not twist the cord during assembly.

Gently pull the cord down and out from the cord entry hole at the bottom section (F) of the luminaire during assembly, to prevent the cord from twisting inside the luminaire.

Check the cord after every three turns when installing the top and bottom sections together.

If the cord has twisted, untwist it by turning the cord anti-clockwise.

3. Install the base (H) onto the bottom section (F) of the luminaire and secure it together by installing the following parts from the underside of the base: Place the flat wedge lock washer (I) onto the threaded rod, followed by the spring washer (J) and thread/secure the hex nut (K) with the included open end spanner (L).

NOTE: Ensure the base (B) is firmly secured, so the entire floor lamp stands upright and stable.

4. Remove the lamp holder ring (C) from the lamp holder.
5. Install the lamp shade (B) onto the lamp holder and secure it with the lamp holder ring (C).
6. Install a lamp (A - not included) into the lamp holder (D). Do not exceed the maximum wattage rating.
7. Select a suitable location for the portable luminaire. See the installation requirements on page 1.
8. Insert the plug (G) into the mains power socket outlet and ensure it is fully plugged in.
9. Turn the power on at the mains power socket outlet.
10. Use the pull cord switch (D) to turn the portable luminaire ON or OFF.

RELAMPING

1. Ensure the power is turned OFF to the portable luminaire and the lamp is fully cooled down before relamping.
2. Remove the old lamp by twisting it anti-clockwise and install a new lamp by twisting it clockwise until it is secure.

Safety tips

- Always ensure the power is OFF and the portable luminaire has cooled down before performing any maintenance, cleaning, changing the lamp or making any adjustment to the portable luminaire.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Children should be supervised to ensure that they do not play with the portable luminaire.
- Handle the luminaire and shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications

SKU #	281107	281108
Colour	Walnut Base with Natural Linen Shade	Oak Base with White Linen Shade
Rated Voltage	220-240V~ 50Hz	
Rated Wattage	45W Max.	
Lamp Holder	ES / E27	
Weight	3.8 kg	
Dimensions	H:1580mm Dia:450mm	