


AXIS SWITCH

WARNING: TO AVOID THE RISK OF ELECTRIC SHOCK.

- Connect the mains supply wire to the socket outlet.



- Ensure the plastic cover plate is installed and secure onto the wall plate..
- Fix the screws covers back onto the cover plate.

NOTE: Failure to fix the screw covers could result in access to live parts/mounting screws.

- Place the face plate onto the Switch plate
- Failure to follow these instructions can result in serious injury or death.

