

FORGE SWITCH

WARNING: TO AVOID THE RISK OF ELECTRIC SHOCK.

- Ensure the plastic cover plate is installed and secure onto the wall plate after the product has been fastened onto the wall and prior to installation of the decorative metal cover plate.
- Push the plastic cover plate down until all 4 corners click and are locked in.
- Failure to follow these instructions can result in serious injury or death.

